

# Refried Beans



**you will  
need:**



**Canned  
Refried Beans**



**Water**



**Shredded  
Cheese**

**tools:**



**Stove Top**



**Pot or Pan**



**Stirring  
Spoon**



**Tablespoon**

# steps

1



Wash your hands



Open the can of refried beans



Pour the can into a pot




Put the pan on the stove top



Add 2TBSP of water

2



Turn the stove top to medium heat



Stir the beans until warm



Careful, it might get hot



Add 1 TBSP water if desired



Stir until warm and mixed well

3



Turn stove off



Top with shredded cheese



Enjoy!